



GR Corolla

CPLT Intake

INSTALLATION INSTRUCTIONS



Tools needed:

- Ratchet
- 10mm socket
- 8mm socket
- Pliers
- Phillips head screwdriver
- Flat head screwdriver


Vehicle Fitment:

- 2023+ Toyota GR Corolla





1. Remove the OEM Radiator Shroud Cover by removing the pop clips with a flat head screwdriver.






2. Remove the vacuum hose shown below and replace with included vacuum cap. This hose junction is located just next to the OEM ribbed intake coupler.






3. Remove the hose from step 2 completely by following it from its start, along the airbox to the airbox flap solenoid attached to the front of the airbox. Remove the hoses from the solenoid carefully. Twisting before pulling down is recommended.







4. Unplug the flap solenoid from the harness and remove it from the airbox. There is an 8mm screw on the bracket and a harness clip on the side of the box. Save the solenoid for later.






5. Unplug the MAF sensor and remove the philips head screws. Then remove the MAF sensor from the airbox. Once the sensor is removed, loosen the hose clamps on each end of the ribbed air tube.






6. Remove the clips holding the airbox scoop, then pull the airbox scoop out of the airbox.







7. Remove the airbox from the engine bay by pulling up off of the rubber mounts. Then remove the ribbed air hose.





8. Using the OEM clamps from the OEM ribbed hose, install the SXTH hose with the hump on the turbo inlet pipe. Only tighten the back clamp hand tight at this time. Once that is tight, install the SXTH intake tube and remaining hose as shown below, leaving the clamps loose.





9. Drop the SXTH airbox into the bay, popping the feet of the box into the OEM mounting locations. You'll have to angle the box and get the hose connected to the airbox at the same time.






10. Rotating the tube might be necessary for a perfect fit. Once the tube is rotated correctly, the hoses will line up where the hose clamps will be right past the lips on the mating parts. Tighten the hose clamps as shown below. Then using the supplied hardware, install the MAF sensor as shown below, then plug it in.





11. Using an OEM pop clip removed earlier, secure the mounting bracket on the SXTH aircoop. After that, install the OEM airbox flap solenoid as shown below with the OEM 8mm screw from earlier. Plug the solenoid in once it is mounted.





12. Install the OEM radiator shroud using the OEM pop clips.





13. Re-install engine cover and you're all done! Enjoy your new intake!





Legal Disclaimer:

SXTH Element Engineering, LLC makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the limited warranty described on our website. SXTH Element Engineering, LLC is hereby specifically excluded from any implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by SXTH Element Engineering, LLC agree to hold harmless and indemnify SXTH Element Engineering, LLC from any and all claims arising from their use. Failure to receive notice of any limitations or the limitations contained in this disclaimer shall not serve to extend liability to SXTH Element Engineering, LLC for any claims arising out of use of its products.

